

★

The BOUNCER has three main air blowers, the blower and the tubes. Choose a set-up area that is approximately 20 feet by 20 feet. (CAUTION: Set-up on a grassy surface only! No concrete or rocks. The area must also be free of hanging tree limbs and power lines.) Place the BOUNCER at the rear of your set-up area and stretch it flat on the ground using the corner bags.

SETTING UP

Use only one of the straps that hold the BOUNCER in all of the tubes in the rear.



★

Slide the strap tube to the rear of the BOUNCER, stretch around the blower outlet and secure it with the attached strap as well as the other binder strap.



Plug each blower into a 115 volt electrical outlet. Make sure the outlets are either NEMA 20 AMP or 30 AMP line circuit. The blower should be the only thing plugged into that circuit. If two blowers are required they must be on separate circuits. Do not use any other extension cords besides the one 30 foot that is already attached to your blower.

★



★

THE BOUNCER MUST BE ANCHORED!!!

Inflation takes about five minutes. The blower runs continuously while the BOUNCER is in use. Once inflated, the BOUNCER can be re-positioned. The anchored area flat position.


The BOUNCER must be anchored on all four sides! Wrap the rope from each side around a stake and drive it into the ground at a 45° angle towards the unit. The stake should be within 32 inches from the unit to prevent whipping. To anchor the anchor, pull up with a firm 1/2" rope to insure that it is secure.




★

TAKING DOWN

Remove children from the BOUNCER and unplug the blower(s). Disconnect the blower from the BOUNCER and open the air tubes. CAUTION: Do not jump on partially inflated BOUNCER.



★

When the BOUNCER is deflated (approximate timing is 10-15 minutes), fold each side to the center. Do not allow the sides to overlap.



★

Next, fold the BOUNCER in half.

Pump Tube @ 4 feet wide
Large Unit @ 3 feet wide



★

Beginning at the front, roll the BOUNCER toward the tubes in the rear.



★

Place the tie straps under the BOUNCER, tuck in the tubes and tie the handle so it is secure.

NOTE: All equipment must be returned on time for security deposit refund.

